

# telliCare2.0

## Contractor Steps

- 1.** Scan QR Code on your unit
- 2.** Begin Start Up + Registration (required for full warranty benefits)
- 3.** Select registration & Start Up enroll in telliCare remote monitoring - Contractors who connect to telliCare during start-up will receive a one year labor warranty on equipment.
- 4.** Receive Hotspot (iQ Floor Models & Wall Units) Neurons & Electrons can connect immediately.
- 5.** Install Hotspot as instructed when it arrives. Contractor receives 1 year labor warranty
- 6.** Customer begins receiving 24/7 Factory Monitoring, text or email alerts, and monthly usage and saving reports. (up to 3 people can be added)

