

- 3. For pipe sizes and gas pressure requirements, please refer to the operation and installation manual.
- 4. Gas pressure regulators to be installed for each unit. Follow manufacturer's installation instructions.
- 5. Water hammer arrestor to be installed within 20 ft of the iQ unit on the hot water supply. Neuron ships with water hammer arrestor installed.
- 6. Y-strainer to be installed according to manufacturer's instructions, horizontal or vertical preferred.
- 7. Temperature and pressure relief valve (shipped with the unit) to be installed on the hot water supply.
- 8. Expansion tank to be sized based on the gallons of water in the plumbing system and to be installed per manufacturer's instruction.
- 9. Venting materials for the booster unit should be CPVC, approved polypropylene, or AL29-4C stainless steel.
- 10. Adjust booster set temperature so that required fixture temperature is obtained on high temperature circuit.

This document/drawing contains confidential and proprietary information and is the property of Intellihot Green Technologies, Inc. This document/drawing was prepared for the sole purpose of soliciting quotes, producing samples, or propose services. It is submitted in confidence on the condition that you and your representatives have, but receiving it, agreed not to reproduce or copy it, in whole of in part, or to furnish such information to others, or to make an other use of it except for the purposes stated above.



