

# Intellihot Process Card



Models Covered: Wall Hung Series – i200/i250, iQ251/iQ251D



## Recommended Bi-Annual Maintenance/PM Check

- Inspect and clean condensate flex line
- Inspect and clean wye strainer located on the cold inlet



## Tools Required

Philips  
Screwdriver

Channel  
Locks



# Intellihot Process Card




Models Covered: Wall Hung Series – i200/i250, iQ251/iQ251D

## Wye Strainer



1. Power the unit down by disconnecting the 120v power.
2. Valve off the main hot outlet and cold inlet lines connected to the water heater, then relieve pressure by opening the relief valve located externally on the hot outlet.
3. Use channel locks to loosen the main 1.75" nut, draining any remaining water from system
4. Inspect/clean mesh strainer basket then reassemble
5. Open the main hot/cold shutoff valves slowly allowing system to pressurize
6. Purge air from the system by opening the hot side of mop sink nearby and letting faucet run for 2-3 minutes before powering the unit back ON

## Condensate Drain Line



1. Remove front cover of wall hung unit, using philips headed screwdriver.
2. Condensate drain line will exist the lower left corner of unit, inspect drain line, clean/replace as necessary. 1/2" drain, secure with zip ties in a trap configuration